





## AVEY ASSEMBLY



A  
4 PCS



B  
1 PC



C  
4 PCS

# STEP 01

ATTACH THE FRAME TO THE SEAT BY SCREWS(A) AND ALLEN WRENCH(B).

